


Mitel 5330-5340 Reference Sheet

HELP SCREENS

☎ Press the blue  **Applications** key, then press **Help**.

The display updates...


Visible are 8 pages of Quick Help topics...

☎ Press the **Key Icons** key  to view 6 pages showing the name & function of the various screen icons.

☎ Press the **Quick Help** key (where **Key Icons** previously appeared) to return to the Quick Help pages.

Note:

Launch PC Help is not active on your system.




CALL HISTORY SCREENS

This is the **BEST** way to view call history!

☎ Press the blue  **Applications** key, then press **Call History**.

The display updates...

Select the category you wish to view. 

Callers will be listed in chronological order, potentially across multiple pages.

Pressing the key next to a specific caller will open the **Call History Details** screen. To return outside calls press **8 + Dial** softkey (or **8 + 1 + Dial** if long distance).

